


RECEIVED

By Tom.Anderton at 10:35 am, Dec 11, 2025

NOTES

Allow to remove modern ceilings and current batten support timbers.
Prop floor joists at centre span.
Add 50x50 timbers to each side of each joist gluing and screwing in place.
Add additional screw fixings @ 225c/c. to further secure existing floor boarding to joists.
Following installation of services, refix ceiling board between joists.
Remove temporary propping on completion of the works.



APPROXIMATE FLOOR SECTION.
(Scale 1:10 @ A4)

STEP COTTAGE, ST MARY'S.
Floor Joist Strengthening Proposals.
SK.18013.01 **October 2025**